
Luxera 1" Mini Blinds Installation and Care Instruction

(optional)



1. <u>Identify your aluminum blind and parts</u> (your parts may vary, depending on the custom request & size of the blind you are purchasing.)










Hold down brackets & screws (optional)

2. Tools you may need (not included)

- Drill with bits
- Metal tape measure
- Screwdriver
- Pen




3. Install the brackets

Mark the bracket locations, making sure the brackets will not interfere with any mechanism or other internal headrail parts. The outermost brackets should be installed about 1/4 inch from each end of the blind. If you have more than 2 hidden brackets, install all remaining brackets towards the center of the blind.


Spacers (optional)


- Install the brackets using screws (included) and tighten them completely.
- Make sure all brackets are aligned and level with each other.

- Install the blind with extension brackets (optional)
 - Install the extension bracket with at least 2 screws.
 - Attach the hidden brackets to the extension brackets with the screws.














4. Attach the blind


- Position the headrail with the front lip resting on the top hooks
- Push the bottom of headrail firmly upward and toward the window until the groove at the bottom of the headrail snaps into place.






5A. How to remove the blind from the brackets

Unlock the hidden brackets with a flat head screwdriver.




6. Attach the tilt wand

Attach the tilt wand onto the wand hook located on the headrail.



7. Attach the optional hold down brackets

- Install the hold down brackets to the wall (for outside mount) or jamb of window frame (for inside mount), not on the sill of window frame.
- Tighten the screws.









8. Care and Clean

- Wipe the blind periodically with a soft dust cloth or dusting mitt, or vacuum with a soft
- You may clean the blinds using a non-scratched sponge or dampened soft cloth with a mild nonabrasive detergent. Never use hot water, solvents, or harsh or abrasive cleansers to clean the blinds
- Note: The warranty for your blinds does not cover damage caused by improper cleaning.









Window blind cord can STRANGLE your child.

To prevent strangulation, purchase cordless products or products with inaccessible cords.

La cuerda de la persiana puede ESTRANGULAR a su niño.

Para evitar el estrangulamiento, compre alternativas cuerda o productos con cuerdas inaccesibles.