


# Simple Fit™ Installation

## Instructions for Inside Mount Installation

### What's Included with your shade:




- Bottom rail handle to assist with shade operation
- Two replacement mounting plates with pre-applied adhesive pads
- Simple Fit™ Spacer

### Before Installation:

**a)** If you ordered several shades, ensure you have the correct shade for each window. Check proper fit by holding shade in the intended window.

**b)** Ensure the surface you are working with is clean and dry. For cleaning information, visit [redishade.com/faq](http://redishade.com/faq)

**c)** Check that the adjustable Trigger End mount (right side) is fully depressed inside the Simple Fit™ mounting system. This should already be done when your shade arrives; if not, press firmly on the mounting plate. The Trigger End is fully in place when you hear a 'click' sound. See visual example to the right.




Press inward on the Trigger End

### Installation:

For how-to video, head to this link: <http://bit.ly/shadeinstall>

1.



2a.



2b.




**1)** Remove tape liner from each Fixed End and Trigger End mounting plates.

**2a)** Place Fixed End (left side) of shade into desired position in window frame. Next, raise and position Trigger End (right side) into position.

**2b)** Lock shade in place by pressing Trigger inward.

### Visual Check:



Check to ensure a red warning line is not visible on Trigger End side of shade. If warning line is visible, remove and reinstall with Spacer (see *Removal and Troubleshooting* for help with this step). After reinstallation, if the warning line continues to be visible, please call us at 855-529-7107.

## Removal and Troubleshooting

### Removal:

1a.



**1a)** To remove shade, grasp shade with both hands and pull firmly toward you to release from mounting plates. Mounting plates will remain affixed to the wall.


1b.



**1b)** Slide a putty knife blade under each mounting plate to gently remove.

### Reinstallation:


2a.



Remove the two mounting plates from Parts bag (see *What's Included*).

**2a)** Slide mounting plates onto both the Fixed End and Trigger End mounts as shown.

2b.




**2b)** Repeat installation.


### Simple Fit™ Spacer (if applicable):

If the red warning line is visible after installation, use the included Spacer to ensure shade is properly installed.


a.



b.



c.



#### Before installing Simple Fit™ Spacer, please check:

- Shade is being installed in the correct window
- Shade width matches size ordered
- Window measurement is correct

**a)** Remove Fixed End mount from left side of head rail.

**b)** Place Spacer over Fixed End mount.

**c)** Reattach Fixed End mount with Spacer by inserting into head rail. Press firmly to secure.

**d)** Repeat Installation steps.

Visit [redishade.com](http://redishade.com)  
for extra installation, troubleshooting tips and videos  
Or give us a call at 1-888-608-6611  
We're HAPPY to help!